<u>**WDM driver Installation Guide**</u>

<u>NB: The following guide is using the fact that you are using Windows 98 SE</u>
(please verify in the System Properties to ensure you have the "Second Edition" . An actual
version of Direct X must be installed – available on the TerraTec CD or by Microsoft.)

<u>Section A:</u>

Remove All INF files related to the TerrraTec card - to do this:
My computer > **View** > **Folder Options** > **View** > tick **Show all files** >**OK**
Go to **My Computer** > **C:** > open the **Windows** folder > **show files** (if
prompted) >open the **Inf** folder > open the **Other** folder > here you must
delete the files relating TerraTec drivers: double click the ***.inf** files to view
the content.

Now unpack in the default location the drivers you have downloaded by
double clicking the TerraTec icon.

<u>Section B:</u>

-Remove the TerraTec Control Panel (software) and drivers from your system
- To do this: select **Start** > **Settings** > **Control Panel** > **Add/remove
programs.**
-You should be able to locate the TerraTec Control Panel (software) in here
and you will need to uninstall it.
- Go to **Start** > **Settings** > **Control Panel** > **System** > **Device Manager** and
click on the plus (+) next to sound and audio devices, here the TerraTec card
should be listed, press the right mouse button and select Uninstall/ Remove.

  Now you will need to reboot your PC

<u>Section C:</u>

The system will now detect a new PCI Multimedia Audio Device found:
- Click **Next** and Select **Search for a better driver (recommended)** then
click **Next**
- ONLY tick **Specify a location** and click **Browse, C:\Terratec_Driver**
Click **OK**
Click **Next**
Click **Next** after you verified the path.
Click **Finish**

Once you have achieved this, you are ready to install the Control Panel
(software). Double click the grey icon for the WDM application. You can
control in the Device Manager if the driver version is the correct one. This can
also be done in the TerraTec software.

If windows does not automatically detect the PCI Multimedia Audio Device
on booting - please try the Multimedia card in a another PCI slot.